



INSTALLATION & OPERATION GUIDE

Please the installation guide before use

1. Confirm compatibility

Before installation, ensure that the end cap component is compatible with irrigation pipe/tape being handled and that all mating parts are secure.

2. Inspect the component

Examine the end cap for cracks, deformation, or other visible damage. Do not use a damaged component.

3. Position the end cap

Place the end cap in a stable position appropriate to the pipe/tape handling operation. Keep it clear of vehicles, sharp edges, and other sources of mechanical damage.

4. Secure the pipe/tape

Feed or attach the irrigation pipe/tape through the end cap arrangement as intended. Ensure it is seated correctly and does not rub excessively against sharp surfaces.

5. End cap/ winding

Wind the pipe/tape evenly without forcing, crushing, or creating sharp kinks. Avoid sudden pulling loads that could damage the irrigation lateral.

6. During handling

Keep hands, loose clothing, and tools clear of moving parts. Stop the operation before correcting a jam or repositioning the component.

7. After use

Remove accumulated soil or debris as practical and inspect the end cap before reuse. Store in a clean, dry location away from prolonged direct sunlight and mechanical damage.

Redyplast — Made in India